

# AVT20 User Manual

EGPRS / LTE Cat-1

V1.01



<b>Document Title</b>	AVT20 User Manual
<b>Version</b>	1.01
<b>Date</b>	December 10, 2024
<b>Status</b>	Release

## Contents

Contents .....	3
0. Revision History .....	4
1. Introduction .....	5
1.1. Specifications .....	5
2. Product Overview.....	6
2.1. Interface Definition .....	6
2.2. Install a SIM Card .....	6
2.3. Install the Internal Backup Battery .....	7
2.4. Power Connection .....	7
2.5. Terminal Status LED.....	7
2.6. G-Sensor Direction.....	8
2.7. Product Parts List .....	9

## 0. Revision History

Revision	Date	Author	Description of Change
1.01	December 10, 2024	Joel	Initial

## 1. Introduction

The AVT20 is a compact GNSS tracker designed for a wide variety of vehicle tracking applications. It has multiple I/O interfaces that can be used for monitoring or controlling external devices. Its built-in GNSS receiver has superior sensitivity and fast time to first fix. Its seven-band LTE-FDD in Europe and GSM/GPRS 850/900/1800/1900 MHz allowing the AVT20's location to be monitored in real time or periodically tracked by a backend server and mobile devices. Its built-in 6-axis accelerometer and gyroscope allows driving behaviour monitoring, motion detection.

### 1.1. Specifications

General Specifications	
Dimensions	97mm*48mm*18mm
Network	1. EGPRS: GSM850/GSM900/DCS1800/PCS1900 2. Cat-1: B1, B3, B5, B7, B8, B20, B28
GNSS (Optional)	GPS, GLONASS, BDS, GALILEO
Bluetooth	BLE 5.3
Sensors & Interface	G-Sensor (6-axis accelerometer and gyroscope)
Battery	3.7V 250mAh Rechargeable Li-polymer Battery
IP Rating	IP67
Power Supply	8 – 90 V
Operating Temperature	-20°C~+60°C
LED indicator	Power LED NET LED GNSS LED
Debug Port	Type C

## 2. Product Overview

### 2.1. Interface Definition

AVT20 has a 2 PIN interface connector that contains the power, GND. the sequence and definition of the 2 PIN connectors are shown in the following table:

PIN	Defined	Color	Comment
1	VIN	Red	External DC power input, 8 - 90V
2	GND	Black	Power and digital ground

### 2.2. Install a SIM Card

Open the case and ensure the unit is not powered. Slide the holder right to open the SIM card holder. Insert the SIM card into the holder as shown below with the gold-colored contact area facing down. Take care to align the cut mark. Close the SIM card holder. Close the case.



### 2.3. Install the Internal Backup Battery

AVT20 has an internal backup 250mAH Li-ion battery.



### 2.4. Power Connection

PWR (PIN1)/GND (PIN2) are the power input pins. The input voltage range for this device is from 7V to 90V. The device is designed to be installed in common vehicles that operate on 12V or 24V systems without the need for external transformers.

### 2.5. Terminal Status LED

LED	Device Status	LED Status
GNSS	GNSS chip is powered off.	OFF
	GNSS sends no data or data format error occurs.	High speed flashing
	GNSS chip is searching GNSS information.	Medium speed flashing
	GNSS chip has gotten GNSS information.	ON
CELL	The device is searching network.	Fast flashing
	The device has been registered on the network.	Slow flashing

PWR	No external power and internal battery voltage is lower than 3.5V.	OFF
	No external power and internal battery voltage is lower than 3.7V.	Slow flashing
	The external power supply has been connected to the device and the internal battery of the device is charging.	Fast flashing
	The external power supply has been connected to the device and the internal battery of the device is fully charged.	ON

**Note:**

CELL LED, GNSS LED and PWR LED can be configured to be turned off after a period time by using the configuration tool.

**2.6. G-Sensor Direction**



AVT20 has an internal 6-axis accelerometer and gyroscope sensor supporting driving behavior monitoring, crash detection and motion detection. The following shows the directions of the motion sensor:



**Motion Sensor Direction**

## 2.7. Product Parts List

Table 1. Parts List

Name	Picture
AVT20 Locator	
3M Backing Sticker	
Case Screw 4pcs	